



part	item code	description	qty	X
(A)	PFS-TB-31	31.5" TUBE	X4	
(B)	PFS-CLLR	COLLAR/SET	X2	
(C)	PFS-FOOT	FOOT/SET	X2	
(D)	PFS-KNOB	KNOB w/ screw	X9	
(E)	PFS-UDRWR-246	24"W SPLIT DRAWER X6"H	X2	
(F)	PFS-UDRWR-2410	24"W SPLIT DRAWER X10"H	X2	
(G)	PFS-DRWR-2410	24"W DRAWER X10"H	X4	
(H)	PFS-DRWR-246	24"W DRAWER X6"H	X1	
	2" #8 screws-black w/ wall anchors - to attach drawer boxs to wall [parts (E), (F), (G) & (H)]		X27	

allen wrench (1), white gloves (1pr), 2"x2"x6" spacers for installation (6), extra set screws (6)

Installation Notes: Drawers come assembled. Remove drawers. Block up drawerbox assembly with top at 32" from finished floor. Attach entire assembly to the wall with provided screws. Next slide legs through the drawers and attach the collars and feet. Legs should protrude approximately 3/8" above top of drawers to accept the sink. Place sink on top. Use a stone safe caulk to seal unit against the wall. Replace drawers in the drawer boxes.

DO NOT SCALE DRAWING



