



Use a stone safe adhesive such as DAP KwikSeal Ultra along brace top, and where brass attaches to sink



C52 Milano Sink with PFS-TDWL Elemental Wall Bracket

Due to the hand-carving of each piece, small variances in shape and size are to be expected.

SIZE **A** DWG. NO. C52 w PFS-TDWL Elemental Wall Brackets REV. **A**

WEIGHT: SHEET 1 OF 1

©2019 Stone Forest, Inc.

DO NOT SCALE DRAWING

link to Youtube for brace installation video:  
<https://www.youtube.com/watch?v=JeCHV377MJY&feature=youtu.be>