

STONE
FOREST


STONE FOREST INSTRUCTIONS

Fountain Installation Kit, 44" Square

44" square x 11"H

Holds 60 gallons of water and up to 3000 lbs of weight

Kit includes: 4 black top plates, 1 gray plate, 8 supports, 4 pump access covers, square basin.



1. Get your shovel out, dig and level out a hole 10" deep, 29" square at the bottom, and sloping to 37" square at the top. Ensure that the ground at the bottom is level and solid (we used play sand from the hardware store in the bottom of the hole to create a nice "level" surface).
2. Place the basin into the hole, with the power cord cut-out facing toward the power source. Level, moving earth or sand around if necessary.
3. Insert the 8 supports into the 8 support holes.
4. Place the center plate (gray) onto the supports, pressing firmly to ensure full installation.
5. Cut a length of tubing long enough to reach from the bottom of the basin to the top of the water feature. Run the tubing through the center hole in the top of the center plate and connect it to the pump outlet fitting. Last page of this document illustrates the hose we make.
6. Install the 4 top plates. On the side nearest the power supply, run the pump power cord out the cord gap, under the edge of the top plate, and through the cord cut-out.
7. Install the 4 access covers, ensuring that the cut-out in each faces outward.
8. Place your Stone Forest water feature on top of the basin in the center, where the 4 top plates meet. Level the fountain using plastic shims.
9. Put the hosing through the center cord-drilled hole in the fountain stone. You'll notice that there is space left around the 1.25" drilled hole and the either 1/2" or 5/8" diameter flexible garden hose that connects to your pump below. To fill the space around the hose and fit it snugly into the top of the core-drilled hole, we wrap the top part of the hose with a strip of pond liner and electrical tape (see last page for reference).
10. Cover the top of the reservoir with smooth river pebbles (or whatever you choose to use to conceal the basin). For this kit, we usually recommend Qty (6) 75-lb bags of the dark river pebbles.
11. Fill your reservoir with water, plug the pump in, and VOILA! Grab a lounge chair and prepare to be relaxed by the soothing sounds of your new fountain.

DISAPPEARING WATER FEATURE BASIN • CUVETTE POUR JEUX D'EAU EN CIRCUIT FERMÉ • CUBETA PARA FUENTE DE AGUA QUE DESAPARECE

EN INTRODUCTION

This instruction sheet provides you with the information required to safely own and operate your Little Giant product. Retain these instructions for future reference.

The Little Giant product you have purchased is of the highest quality workmanship and material, and has been engineered to give you long and reliable service. Little Giant products are carefully tested, inspected, and packaged to ensure safe delivery and operation. Please examine your items carefully to ensure that no damage occurred during shipment. If damage has occurred, please contact the place of purchase. They will assist you in replacement or repair, if required.

READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE, OR SERVICE YOUR LITTLE GIANT PRODUCT. KNOW THE PRODUCT'S APPLICATION, LIMITATIONS, AND POTENTIAL HAZARDS. PROTECT YOURSELF AND OTHERS BY OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH THESE INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE!



INSTALLATION (DFB44)

Refer to Figure 2 and the following instructions to install the DFB44 basin:

1. Dig a hole 10" deep, 29" square at the bottom, and sloping to 37" square at the top. Ensure that the ground at the bottom is level and solid.
2. Place the basin into the hole.
3. Insert the 8 supports into the 8 support holes.
4. Place the center plate (gray) onto the supports, pressing firmly to ensure full installation.
5. Place the pump into the basin.
6. Cut a length of tubing long enough to reach from the bottom of the basin to the top of the water feature.
7. Run the tubing through the center hole in the top of the center plate and connect it to the pump outlet fitting.
8. Install the four top plates. On the side nearest the power supply, run the pump power cord out the cord gap, under the edge of the top plate, and through the cord cut-out.
9. Install the four access covers, ensuring that the cut-out in each faces outward.
10. Refer to the water feature owner's manual to complete the installation.




Figure • Figure • Figura 2 - DFB44

LIMITED WARRANTY

Your Little Giant product is guaranteed to be in perfect condition when it leaves our Factory. It is warranted against defective materials and workmanship for a period of 12 months (90 day warranty on Models: 1-AA-OM, GKPK-SC, PP-1, PPS-1, PP-12, PPS-12, PP-230 and Cooler King) from date of purchase by the user. No warranty on brush wear in Model 35-OM and impeller or cam in Models PP-1, PP-12, and PP-230.

Any product that should fail for either of the above two reasons and is still within the warranty period will be repaired or replaced at the option of Little Giant as the sole remedy of buyer. For our customers in the CONTINENTAL UNITED STATES: Please return the defective unit, postage paid, to the factory at 301 N. MacArthur, Oklahoma City, OK 73127-6616. All defective product returned under warranty will be fully inspected to determine the cause of failure before warranty is approved.

For our customers located elsewhere; it is not economical, due to duties and freight, to return the pump to the factory for inspection. Please return the defective unit to any authorized distributor or dealer with a brief written explanation of the problem. If there are no apparent signs of customer abuse, unit will be repaired or replaced. If dispute arises over replacement of the pump, the distributor or dealer is to segregate such items and hold for inspection by a representative of Little Giant or notify factory with details of the problem for factory disposition and settlement of warranty claim.

DISCLAIMER: THE FOREGOING WARRANTY IS AN EXCLUSIVE WARRANTY IN LIEU OF ANY OTHER EXPRESS WARRANTIES. ANY IMPLIED WARRANTIES (INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) TO THE EXTENT EITHER APPLIES TO A PUMP SHALL BE LIMITED IN DURATION TO THE PERIODS OF THE EXPRESS WARRANTIES GIVEN ABOVE.

Warranty will be **VOID** if any of the following conditions are found:

1. Sealed motor housing opened.
2. Product connected to voltage other than indicated on nameplate.
3. Cord cut off to a length less than three feet.
4. Pump allowed to operate dry (fluid supply cut off).
5. Pump used to circulate anything other than fresh water, light oils, or other mild liquids at approximately room temperature.
6. Product abuse by customer.

Any oral statements about the product made by the seller, the manufacturer, the representatives or any other parties, do not constitute warranties, shall not be relied upon by the user and are not part of the contract for sale. Seller's and manufacturer's only obligation, and buyer's only remedy, shall be the replacement and/or repair by the manufacturer of the product as described above.

NEITHER SELLER NOR THE MANUFACTURER SHALL BE LIABLE FOR ANY INJURY, LOSS OR DAMAGE, DIRECT, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, BUT NOT LIMITED TO INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL LOSS), ARISING OUT OF THE USE OR THE INABILITY TO USE THE PRODUCT AND THE USER AGREES THAT NO OTHER REMEDY SHALL BE AVAILABLE TO IT.

Before using, the user shall determine the suitability of the product for the intended use, and user assumes all risk and liability whatsoever in connection therewith.

Some states and countries do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and country to country.

The National Electric Code (in the USA) and similar codes in other countries require a Ground Fault Circuit Interrupter (GFCI) to be installed in the branch circuit supplying fountain equipment rated above 15 volts. 115 volt GFCI's (with various cord lengths) are in stock, and we recommend each pump be used with a GFCI.

44" Square Fountain Installatin Kit







Diagram of Simple Recirculating Fountain Installation





Supplied hose

Instructions to connect the hose to the submersible pump for your fountain:

- Make sure that your fountain is in place and ready.
- Take the provided hose and feed it down through the center drilled hole in the stone fountain. The hole is approximately 1.25" in diameter, which will leave space around the hose. There is a plug on one end which will friction fit at the top of the fountain drilling. Depending on the size of your pump, you will have been supplied either a 1/2" or 5/8" diameter hose.
- We wrap one end of the hose with a strip of pond liner and electrical tape to ensure a tight fit at the top of the drilled hole. If the plug is too small to stay in place, you may need to remove the electrical tape and add some pond liner then retape to increase the diameter.
- Finally, connect the end of the hose in the reservoir to the submersible pump sitting on the floor of the reservoir.



steps to creating the plug end of the hose